

Soft-Case for Tenor-Saxophone

Soft bag for tenor saxophone

Réf. : 26600215

GTIN: 4026397192070



L'article n'est plus disponible.

Soft-Case for Tenor-Saxophone

Soft bag for tenor saxophone

Réf. : 26600215

GTIN: 4026397192070

Caractéristiques:

- Nylon material
- Color: blue
- High grade quality
- Padded and stable
- Compact and handy
- With handle
- This case guarantees robust protection and secure transport